



HEAT PUMP WINTER COVER

Fitting Instructions

Thank you for purchasing a winter cover from HeatPumps4Pools.com. Our covers are purpose designed to provide winter weather protection for your valuable pool heat pump. They are constructed with a special vent section to allow any moisture build up to escape. The covers are also made with a deliberately "baggy" fit to allow air circulation.

CONTENTS:

- 1 x Cover
- 2 x Adjustable Straps
- 1 x Velcro cover strip
- 1 x Velcro self adhesive tape

TOOLS NEEDED:

- Scissors or craft knife
- Marker pen

FITTING INSTRUCTIONS

1. Open the cover and drop it over the heat pump.
2. If you have horizontal inlet/outlet pipes, fold up the bottom of the cover to be just above the flow and return pipes



3. Using a marker pen, mark the height and position of the flow and return pipes on the cover

4. Mark the height and position of the power inlet cable



Remove the cover from the heat pump then:

5. Using sharp scissors, cut two vertical slots from the bottom edge of the cover to where you have marked the top of the inlet and outlet pipes (or, if pipes are positioned vertically above each other, cut a single vertical slot to the top of the highest pipe)



Note that covers for Heat Siphon units may have the vertical slot pre-cut

6. Cut a similar vertical slot for the power input cable if necessary
7. Refit the cover on the heat pump

8. Apply self-adhesive Velcro to both sides of slot and fit the Velcro cover strip supplied over the slot



9. Trim the strip to the required length

10. Fit one of the straps just above the inlet/outlet pipes (or just above the lower pipe)



11. Fit the second strap about one third down from the top of the unit



Note: Do not attempt to operate the heat pump with the cover in place. The cover is intended to protect your heat pump from the weather when it is not in use. Fully remove the cover before operating your heat pump.

Cleaning: Wash the cover with warm soapy water and a sponge or cloth

Thank you HeatPumps4Pools.com